

 In this user manual we have tried to describe the matters concerning the operation of this CNC system to the greatest extent. However, it is impossible to give particular descriptions for all unnecessary or unallowable operations due to length limitation and products application conditions; Therefore, the items not presented herein should be regarded as " impossible " or " unallowable " .

 Copyright is reserved to GSK CNC Equipment Co., Ltd. It is illegal for any organization or individual to publish or reprint this manual. GSK CNC Equipment Co., Ltd. reserves the right to ascertain their legal liability.

## Preface

Your Excellency,

We are honored by your purchase of this GSK 983Ta Turning CNC System made by GSK CNC Equipment Co., Ltd.

## Warning



Accident may occur by improper connection and operation ! This system can only be operated by authorized and qualified personnel.

Please read this manual and a manual from machine tool builder carefully before installation, programming and operation, and strictly observe the requirements. Otherwise, products and machine may be damaged, workpiece be scrapped or the user be injured.

## Safety Responsibility

### Manufacturer's Responsibility

- Be responsible for the danger which should be eliminated and/or controlled on design and configuration of the provided CNC systems and accessories.
- Be responsible for the safety of the provided CNC systems and accessories.
- Be responsible for the provided information and advice for the users.

### User's Responsibility

- Be trained with the safety operation of CNC system and familiar with the safety operation procedures.
- Be responsible for the dangers caused by adding, changing or altering to the original CNC systems and the accessories.
- Be responsible for the failure to observe the provisions for operation, adjustment, maintenance, installation and storage in the manual.

**This manual is reserved by end user.**

**We are full of heartfelt gratitude to you for supporting us in the use of GSK's products.**

# Contents

Precautions .....	1
1. NC Unit Interfaces .....	3
2. Interconnect Block Diagram .....	4
3. Connection between NC Unit and GS2000T-CA1 Drive Unit.....	5
(without brake) .....	5
4. Connection between NC Unit and GS2000T-CA1 Drive Unit.....	6
(with brake) .....	6
5. Full closed-loop connection with Grating Ruler .....	7
6. Connection between NC Unit and DAP03 Spindle Servo Drive Unit .....	8
7. Connection between NC Unit and GS3000Y-NP2 Spindle Servo Drive Unit.....	9
8. Connection between NC Unit and Spindle Inverter .....	10
9. Machine Tool Operation Panel .....	11
10. Connection between NC Unit and Operation Panel .....	12
11. Connection between external MPG and Operation Panel.....	13
12. Connection between NC Unit and PC .....	14
13. Connection Method for Brake and System Power-on Control .....	15
14. Connection between NC Unit and I/O Unit .....	16
15. General of External I/O Unit (X1) Interfaces .....	17
16. Connectivity Diagrams for I/O Unit (X1) Input/Output Signals .....	18
17. I/O Points Definition (X1) .....	19
Appendix 1 Installation Dimension Drawings .....	23
Appendix 2 Connection between NC Unit and DA98D Drive Unit (obsolete product) .....	28
GSK983Ta-H/ GSK983Ta- V Turning CNC System Connection Manual .....	30
Version Upgrading Records .....	30



## Precautions


**1、The system-matched power supply box is exclusive for GSK 983Ta. Do not supply this power to other devices (such as bake and magnetic valve);otherwise, serious danger may occur!**

### 2、Requirements for electrical cabinet

The electrical cabinet adopts full-enclosed structure and dustproof design. The temperature difference between outside and inside of the cabinet should be less than 10°C; or, a heat-exchange system should be installed. The ambient temperature should not exceed 45°C. Prevent the entry of dust, coolant and organic solution.

### 3、Grounding

The cabinet should be protectively grounded, and the continuity should meet the requirement GB5226.1-2002. Well grounding is the essential condition for a stable operation. The grounding wires of different parts cannot be connected with each other in series. The grounding strip whose thickness not less than 3mm should be installed in the cabinet, the protective grounding terminals should be connected to grounding strip with yellow-green wires independently, and when the grounding strip is connected with the ground, its grounding resistance should be less than 4Ω.




**4、The system power should be supplied through isolation transformer**

### 5、Wiring

The joints between wires and the system or drive unit should be tight and firm. The low-current type wires such as signal wires and control wires should be laid far away from heavy current and electromagnetic interference, and be arranged in an uncurled manner as far as possible, because winding annularly could easily cause the acquisition of interference signal..


### 6、 Interference suppression

Connect the RC circuits at the two ends of AC coil in parallel. The RC circuits should be closed to inductive load as far as possible. Connect FWD at the ends of DC coil reversely in parallel. Connect the surge absorber at the winding head of AC motor.




# 1. NC Unit Interfaces


Front View





Back View



## 2. Interconnect Block Diagram





### 3. Connection between NC Unit and GS2000T-CA1 Drive Unit (without brake)




- PCA \*PCA: Encoder feedback A phase differential signal (pulse signal, drive unit→NC)
- PCB \*PCB: Encoder feedback B phase differential signal (pulse signal, drive unit→NC)
- PCZ \*PCZ: Encoder feedback Z phase differential signal (pulse signal, drive unit→NC)
- SON+/-: Enable signal (binary signal, NC→ drive unit)
- SRDY: Servo drive ready signal (binary signal, drive unit→NC)
- VC: Speed control voltage (direct current, NC→drive unit)

Note : when the X axis is connected without brake, the connection of X or Z axis is the same. The X axis connection with brake is shown in the following page.

## 4. Connection between NC Unit and GS2000T-CA1 Drive Unit (with brake)



### 5. Full closed-loop connection with Grating Ruler



## 6. Connection between NC Unit and DAP03 Spindle Servo Drive


### Unit

Spindle Servo Drive Unit:

DAP01or DAP03

983Ta-00-785

NC Unit




Note: The corresponding positions of I/O Unit are described in PLC User Manual of the same version.

## 7. Connection between NC Unit and GS3000Y-NP2 Spindle Servo

### Drive Unit


Suffixing with N (no-bus)

GS Spindle Servo Drive Unit




Note: The corresponding positions of I/O Unit are described in PLC User Manual of the same version.

## 8. Connection between NC Unit and Spindle Inverter





Note 1: The corresponding positions of I/O Unit such as M03 and M04 are described in PLC User Manual of the same version.

Note 2: When the spindle speed arrival check signal \*SAR is not used, it should be shorted to 0V (valid when the input interface is at low level) or be shorted to 24V (valid when the input interface is at high level).



## 9. Machine Tool Operation Panel



- POFF (Power off)
- PCOM (Power switch common port)
- PON (Power on)
- ESPC (Emergency stop chain leading-out terminal2)
- ESPB (Emergency stop button on operation panel leading-out terminal2)
- ESPA (Emergency stop button on operation panel leading-out terminal1; Emergency stop chain leading-out terminal 1)

**CC2**  
(D-9 male)

01	0V	06	TD-	TD+ TD-: RS422 differential sending terminal
02	TD+	07	RD-	RD+ RD-: RS422 differential receive terminal
03	RD+	08	HA-	HA+ HA-: MPG A phase pulse output
04	HA+	09	HB-	HA+ HA-: MPG B phase pulse output
05	HB+			

Communication


CN3(D-25 Female) is not used

**CM1**  
(D-25male)

01	HX	14		HX、HZ: External MPG axis select signal
02	HZ	15		
03		16	×1	×1、×10、×100: External MPG override Select signal
04	×10	17	×100	
05	+L (24V)	18	-L (0V)	-L、+L: 2 poles of external MPG indicator
06	ESP2	19	ESP1	ESP2、ESP1: 2 poles of external MPG emergency stop button
07		20	0V	
08	HA+	21	HA-	HA+、HA-: External MPG A phase pulse input
09	HB+	22	HB-	HB+、HB-: External MPG B phase pulse input
10	0V	23		
11	0V	24		
12	+5V	25		
13	+5V			


MPG

Note: External MPG and MPG on the operation panel cannot use at the same time.





I/O unit side

Note: when external MPG is used, emergency stop chain should be formed by emergency stop buttons on operation panel and external MPG



## 10. Connection between NC Unit and Operation Panel




RD2+ RD2-: RS422 differential receive terminal

TD2+ TD2-: RS422 differential sending terminal

HA+ HA- : MPG A phase input



HB+ HB- : MPG B phase input

## 11. Connection between external MPG and Operation Panel





\*Note: axis select signals HX,HZ of CM1 and override signals ×1,×10,×100 of pin No. are defined by PLC, and pin No. can be different in different visions of PLC. So, check the operations of the corresponding PLC before connecting.

## 12. Connection between NC Unit and PC





Note: the shell of NC and PC should be grounded firmly.

### 13. Connection Method for Brake and System Power-on Control




### 14. Connection between NC Unit and I/O Unit



TX1+、TX1-: RS422 differential signal sending  
 RX1+、RX1-: RS422 differential signal sending receive

### 15. General of External I/O Unit (X1) Interfaces



## 16. Connectivity Diagrams for I/O Unit (X1) Input/output Signals


### 1. Input Signal

The COM ports of each address group determine whether the addresses are valid at high or low level:


When COM port is connected to 24V, the input points are valid at low level (0V) ;

When COM port is connected to 0V, the input points are valid at low level (24V) .

Connection when low level is valid



Connection when high level is valid




Note: There are 64 input points in 8 different groups. The figure above is taken X32.0-X32.7 for example; other groups are alike.

### 2. Output Signal

There are 40 points for ULN2803 output. The maximum passing current of each point is 200mA.

Connectivity Diagram of Output Point



## 17. I/O Points Definition (X1)

Terminal No.	PLC Address	Signal Name	Signal Function	I/O
<b>X32.COM</b>		<b>X32 common port</b>	High/low selection for group X32	
<b>X32.0</b>	<b>X32.0</b>	<b>*+LX (fixed)</b>	X axis " + " direction limit (short it to 0V when unused)	I
<b>X32.1</b>	<b>X32.1</b>	<b>*-LX (fixed)</b>	X axis " - " direction limit (short it to 0V when unused)	I
X32.2	X32.2			I
X32.3	X32.3			I
X32.4	X32.4			I
<b>X32.5</b>	<b>X32.5</b>	<b>*DECX (fixed)</b>	X axis zero-point return deceleration	I
X32.6	X32.6			I
X32.7	X32.7			I
<b>X33.COM</b>		<b>X33 common port</b>	High/low selection for group X33	
<b>X33.0</b>	<b>X33.0</b>	<b>*+LZ (fixed)</b>	Z axis " + " direction limit (short it to 0V when unused)	I
<b>X33.1</b>	<b>X33.1</b>	<b>*-LZ (fixed)</b>	X axis " - " direction limit (short it to 0V when unused)	I
X33.2	X33.2			I
X33.3	X33.3			I
X33.4	X33.4			I
<b>X33.5</b>	<b>X33.5</b>	<b>*DECZ (fixed)</b>	Z axis zero-point return deceleration	I
X33.6	X33.6			I
X33.7	X33.7			I
<b>X34.COM</b>		<b>X34 common port</b>	High/low selection for group X34	
<b>X34.0</b>	<b>X34.0</b>			I
<b>X34.1</b>	<b>X34.1</b>			I
X34.2	X34.2			I
X34.3	X34.3			I
X34.4	X34.4			I
<b>X34.5</b>	<b>X34.5</b>			I
X34.6	X34.6			I
X34.7	X34.7			I
<b>X38.COM</b>		<b>X38 common port</b>	High/low selection for group X38	
X38.0	X38.0			I
X38.1	X38.1			I
X38.2	X38.2			I
X38.3	X38.3			I
<b>X38.4</b>	<b>X38.4</b>	<b>*ESP (fixed)</b>	Emergency stop (input)	I
X38.5	X38.5			I
X38.6	X38.6			I
X38.7	X38.7			I

Terminal No.	PLC Address	Signal Name	Signal Function	I/O
<b>X48.COM</b>		<b>X48 common port</b>	High/low selection for group X48	
X48.0	X48.0			I
X48.1	X48.1			I
X48.2	X48.2			I
X48.3	X48.3			I
X48.4	X48.4			I
X48.5	X48.5			I
X48.6	X48.6			I
X48.7	X48.7			I
<b>X43.COM</b>		<b>X43 common port</b>	High/low selection for group X43	
X43.0	X43.0			I
X43.1	X43.1			I
X43.2	X43.2			I
X43.3	X43.3			I
X43.4	X43.4			I
X43.5	X43.5			I
<b>X43.6</b>	<b>X43.6</b>	<b>SKIP.M</b>	Block skip signal input	I
X43.7	X43.7			I
<b>X35.COM</b>		<b>X35 common port</b>	High/low selection for group X35	
<b>X35.0</b>	<b>X35.0</b>			I
<b>X35.1</b>	<b>X35.1</b>			I
X35.2	X35.2			I
X35.3	X35.3			I
X35.4	X35.4			I
<b>X35.5</b>	<b>X35.5</b>			I
X35.6	X35.6			I
X35.7	X35.7			I
<b>X40.COM</b>		<b>X40 common port</b>	High/low selection for group X40	
X40.0	X40.0			I
X40.1	X40.1			I
X40.2	X40.2			I
<b>X40.3</b>	<b>X40.3</b>	<b>XAG.M</b>	X axis auto tool compensation	I
<b>X40.4</b>	<b>X40.4</b>	<b>ZAG.M</b>	Z axis auto tool compensation	I
X40.5	X40.5			I
X40.6	X40.6			I
X40.7	X40.7			I


Terminal No.	PLC Address	Signal Name	Signal Function	I/O
Y0.0	Y0.0			O
Y0.1	Y0.1			O
Y0.2	Y0.2			O
Y0.3	Y0.3			O
Y0.4	Y0.4			O
Y0.5	Y0.5			O
Y0.6	Y0.6			O
Y0.7	Y0.7			O
Y1.0	Y1.0			O
Y1.1	Y1.1			O
Y1.2	Y1.2			O
Y1.3	Y1.3			O
Y1.4	Y1.4			O
Y1.5	Y1.5			O
Y1.6	Y1.6			O
Y1.7	Y1.7			O
Y2.0	Y2.0			O
Y2.1	Y2.1			O
Y2.2	Y2.2			O
Y2.3	Y2.3			O
0V			24V power ground	
+24V			24V power output	O

Terminal No.	PLC Address	Signal Name	Signal Function	I/O
Y3.0	Y3.0			O
Y3.1	Y3.1			O
Y3.2	Y3.2			O
Y3.3	Y3.3			O
Y3.4	Y3.4			O
Y3.5	Y3.5			O
Y3.6	Y3.6			O
Y3.7	Y3.7			O
Y6.0	Y6.0			O
Y6.1	Y6.1			O
Y6.2	Y6.2			O
Y6.3	Y6.3			O
Y6.4	Y6.4			O
Y6.5	Y6.5			O
Y6.6	Y6.6			O
Y6.7	Y6.7			O
Y2.4	Y2.4			O
Y2.5	Y2.5			O


Y2.6	Y2.6			○
Y2.7	Y2.7			○
0V			24V power ground	
+24V			24V power output	○

**Note:** Those points which have been defined functions are fixed in the system that cannot be changed any more by users. And functions of other points can be programmed by PLC.







Drill Pattern Installation Dimension (1:2)




Note: there are several versions concerning the panel rear cover dimension and the "Drill Pattern and Installation Dimension" is compatible with all versions; therefore, the drill pattern should be strictly followed.




### 983Ta-H Operation Panel Installation Dimension









Drill Pattern Installation Dimension



Note: there are several versions concerning the panel rear cover dimension and the "Drill Pattern and Installation Dimension" is compatible with all versions; therefore, the drill pattern should be strictly followed.





### 983Ta-V Operation Panel Installation Dimension



## Appendix 2 Connection between NC Unit and DA98D Drive Unit (obsolete product)

### Connection without brake





- PCAX \*PCAX: Encoder feedback A phase differential signal(pulse signal, drive→NC)
- PCBX \*PCBX: Encoder feedback B phase differential signal(pulse signal, drive→NC)
- PCZX \*PCZX: Encoder feedback Z phase differential signal(pulse signal, drive→NC)
- SONX+/-: Enable signal(switch signal,NC→drive)
- ALMX: alarm signal (switch signal, drive→NC)
- VCX: Speed control voltage (direct voltage, NC→drive)

Note 1: When X axis is not with brake, the connection of X or Z axis is the same. Connection of X axis with brake, please see to the following page.

Note 2: According to this connection method, the rotation direction of the motor is consistent with Cartesian coordinate system, that is, seen from motor axle head, the feeding direction is positive direction. If the converse direction is needed, set PA46 parameter of DA98D to 3(Default value is "0").

### Connection without brake



# GSK983Ta-H/ GSK983Ta- V Turning CNC System Connection Manual

## Version Upgrading Records

No.	Date	Version	Content
1	2012-6-19	First Version	